

VIZION



VIZION WIRELESS MONITORING SYSTEM INSTRUCTIONS

PART NUMBERS: VZ1000, VZBT1000



TABLE OF CONTENTS

INTRODUCTION	pg. 2
INSTALLATION	pg. 3
WIFI CONNECTION	pg. 4
BLUETOOTH CONNECTION	pg. 5
NAVIGATION / FEATURES	pg. 6
MAIN MENU	pg. 9
WARRANTY	pg. 14
DISCLAIMER	pg. 15

INTRODUCTION

Thank you for your purchase of a Quadzilla product. We know you'll be more than satisfied with the increased performance our product provides. Be sure to tell your fellow diesel truck owners about Quadzilla.

This product may alter the technician's ability to use diagnostic equipment. Please remove this Quadzilla product when taking your truck into a service facility.

The installation of this product indicates the BUYER has read and understands this agreement and the 'Disclaimer of Liability' agreement contained at the end of this document and accepts its terms and conditions.



Prior to installation of the Vizion please make sure you have downloaded the Vizion app to the device you will be using for monitoring your vehicle. Immediately after downloading the Vizion app follow these steps:**

1. Start the app and go into the Main Menu
2. Then go into Vehicle Selection Menu while connected to the internet
3. Find your vehicle and select it by simply touching it.

**If you have a cellular connection you will be able to do these steps at any time.

Note: It is not required but it is recommended to repeat these steps occasionally to check for new vehicle profile updates.

Once you are ready to install the Vizion, you will need to locate the OBD2 port on your vehicle. This port is located just below the bottom of the knee panel. The Vizion simply plugs into this port.





WiFi CONNECTION TO THE VIZION:

ALL APPLE DEVICES

After downloading the app from the App Store and installing your Vizion you will be required to connect to the Vizion Wireless Network. Usually this connection will become automatic once the initial setup is done.

To do this you will need to turn your truck on or at least turn the key to the on position. You will then need to go to the settings icon on your device and go into the WIFI settings. Make sure the on/off toggle is turned on.

Within a few second the device should find the Vizion WIFI Network. It will be named Vizion_XXXXX. (5 digit number) This is your Vizion serial number. Select this network by touching it and within a few second your will should be completely connected to your Vizion system.

You can now exit our of your Settings icon and go into your Vizion app to begin monitoring your vehicle.






BLUETOOTH CONNECTION TO THE VIZION: ALL ANDROID DEVICES

After downloading the Vizion App from the Android market and installing the Vizion you will now be required to connect the Vizion Bluetooth Network.

To do this you will need to turn the truck on or at least turn the key to the on position. You will need to go into the Vizion app and the first thing you will see is a screen that will allow you to scan for paired devices. It should come up with Vizion at the top and there should not be any paired devices listed. You will need to then hit the "Scan" button. Once the Vizion you have plugged into your truck is detected it will show up as Vizion_XXXXX. (5 digit number) This is your Vizion serial number. Select this network by touching it then you will be prompted to enter a password. You must enter 1234 to pair the device. Once this is done it should show up under the Paired Devices list.



To begin using your Vizion you can go into the Main Menu screen by hitting your Menu Button.





For full Color Instructions please visit our website .

VISION NAVIGATION/FEATURES



** Power Level Indicator and controls are only applicable on the 06-11 Dodge Trucks running a MADS Smarty POD.



Yellow Parameter Icon indicates a Warning for this Parameter that is currently on the Main Display



Yellow Palette indicates a Warning for a Parameter that is NOT currently on the Main Display

Yellow Warning Icon indicates a Warning for a Parameter that is currently on the Main Display

Yellow Soot/SoX Icons will appear for soot and sox regen indicators for vehicles that go through regeneration



VIZION NAVIGATION/FEATURES [CONTINUED]

Secondary gauges are not loaded when you first open your app. You will see the outline of the gauges and you may simply drag and drop the desired parameters into these locations to turn them on. To turn these locations off simply touch the red "x" that is shown by each gauge anytime the palette is open. You may change parameters as often as you like and do so anytime you choose.



Parameter Palette

Touch the top of the drawer and drag up or down to open and close the palette. Once open use finger swipes left and right to scroll through available parameters

To select a parameter to be used on the main display, touch and hold for 2-3 seconds. The parameter will "grow" and the description of that icon will be displayed at the top of your screen. You can then drag the icon to the desired location and once in place, remove your finger.



The Vizion also offers 3 gauge setups.

1. All Analog setup which gives you the ability to view 5 parameters.
2. Analog/Digital display which gives you the ability to view 10 parameters
3. All Digital display which gives you the ability to view 9 parameters

To navigate between the 3 gauge setups a finger swipe from left to right will take you to the different options.

Bluetooth Notes:

Menu button will take you to the Main Display at any point within the Vizion App.

Home button will kill the app and take you back to your home screen however the app will remain running in the background.

Back button helps navigate through the app by taking you to the previous screen.

The back button also kills the app when used from the Main Display.



MAIN MENU


- Vehicle Selection
- Settings
- Data Logging
- Diagnostics

The vehicle selection and settings menu's are found inside the main menu.

VEHICLE SELECTION:

If you need to change vehicles make certain that you are first connected to the internet and simply switch to the vehicle you wish to connect to. This will load the corresponding parameter and feature list into your device. Each time you do this you will lose all previously stored data and gauge selections.

From time to time we will release vehicle updates that will be available without going through the app store. To check for these updates just re-select your vehicle, if an update is available you will be notified, if no update is available you will be returned to the main menu.





SETTINGS

DRIVE TRAIN INFO

To change Drive Train Info touch the setting then select from a drop down list of available options:

Transmission ID: You will have option to choose Automatic, Manual 5 Speed or Manual 6 Speed

Rear End Ratio: You will have an option to choose your rear end ratio

Tire Size: A keyboard will appear allowing you to type in the circumference of your tire

SMARTY CONTROL **

TFor 06-11 Dodge Trucks wishing to use the Vizion for control of your Smarty POD, you will have an additional listing under Settings for Smarty Control. This option allows you to control the levels of your Smarty from 49-99 when used with the POD. To enable this feature simply touch the icon. You now should have control of the Smarty and also be able to see your power level on the Vizion. Note: The only way this setting will be available to you is if under the Vehicle Selection Menu you have chosen the correct vehicle year that reads "Smarty Control". If you have not chosen this then please make sure you are connected to the internet and go back to vehicle selection and choose the correct one.


**Only available for 06-11 Dodge Trucks running a MADS Smarty POD





DATA LOGGING

This option allows you to view all of your minimum and maximum values. This data can be cleared at any time by hitting the clear button at the top of the screen.

A screenshot of a mobile application interface titled "Data Logging". The screen shows a list of engine parameters with their respective maximum and minimum values. A "Clear" button is located in the top right corner of the data list. The status bar at the top of the screen shows various icons including Bluetooth, Wi-Fi, cellular signal, and battery level, along with the time "3:08 PM".

Parameter	Value
Boost Pressure	Max:0PSI
Coolant	Max:-40°F
ECM Voltage	Min:0.0V Max:0.0V
EGT	Max:0°F
Engine Load	Max:0%
Intake Air Temperature	Max:-40°F
Rail Pressure	Max:0PSI



DIAGNOSTICS

DTC - If at any time you receive a Check Engine Light, you will be able to view the DTC code with the Vizion app by going to the DTC option. You will also be able to erase the code by choosing Clear DTCs.

DTC DATA - This will show you any information regarding any clearing of DTCs including Time Since DTC Cleared, Distance Since DTC cleared and Warmups Since DTCs cleared.

DPF INFO - This will show you all of your information regarding Regeneration including your filter load and last regeneration time.

WARRANTY

All QUADZILLA Performance Modules/Tuners Diesel Performance Enhancement Software- as specified below - is warranted against defective materials or workmanship for one million miles or ten years from date of purchase, whichever comes first. The Performance Modules/Tuners hardware units are covered by a one year unlimited mileage warranty.

WHAT IS WARRANTED:

Any Performance Modules/Tuners Diesel Performance Enhancement Software specified for and Cummins, Powerstroke, and, Duramax diesel engines, except those units sold exclusively for racing and/or off-road use.

WHO IS COVERED BY WARRANTY:

The original purchaser of a Performance Modules/Tuners who has completed the required warranty registration and provided proper proof of the original retail purchase and all other required information.

WHAT IS NOT WARRANTED:

Any Performance Modules/Tuners used for any type of racing or competition, any off-road use, custom or modified applications, any non-legal or industrial applications. (These units are covered by a one year unlimited mileage warranty for both Software and Hardware.)

WHAT VOIDS THE WARRANTY:

Incorrect Installation: The Performance Modules/Tuners must be installed following Quadzilla installation procedure as outlined in the product literature that accompanies the Performance Modules/Tuners. Physical damage to the unit due to improper care in installation or removal will not be covered under this warranty. **No Registration:** Failure to register your product within 90 days of purchase will void the one year unlimited mileage warranty. **No Proof of Purchase:** At time of warranty claim, buyer must provide proof of purchase (original receipt or invoice). **Incorrect Use:** Any damaged, abused or modified Performance Modules/Tuners will not be warranted.

EXTENT OF WARRANTY:

Any defective Performance Modules/Tuners properly returned to QUADZILLA will be replaced or repaired by QUADZILLA. QUADZILLA will not be responsible for any other expenses incurred by the customer under the terms of this warranty, nor shall it be responsible for any damages consequential, special, contingent, or otherwise; or expenses or injury arising directly or indirectly from the use of the Performance Modules/Tuners unit or software. Any Performance Modules/Tuners returned to QUADZILLA must be sent at the customer's expense along with proof of purchase. QUADZILLA reserves the right to determine whether the terms of the warranty, set out above, have been properly complied with. In the event that the terms are not complied with, QUADZILLA shall be under no obligation to honor this warranty.

SHORTAGES AND DAMAGED GOODS:

It is the responsibility of the customer to inspect and count products upon receipt. Any shortages or errors must be reported to Quadzilla immediately. Claims for shortages or damaged goods must be received within 3 days of receipt of the product. All merchandise is inspected before packing. Any damaged goods should be reported to the freight carrier immediately. All packaging of damaged goods must be kept for inspection by the freight carrier.

RETURNS AND EXCHANGES:

An RMA (return merchandise authorization) must accompany all returns and exchanges. Returns must include a copy of the original invoice. Returns and exchanges must be shipped pre-paid or they will be refused.

Returned or exchanged products must be undamaged, or in "like new" condition. Damage occurred during freight due to improper packing is the responsibility of the customer. Unauthorized or refused merchandise are subject to a 10% restocking fee.

* LEGAL IN CALIFORNIA ONLY FOR RACING VEHICLES WHICH MAY NEVER BE USED UPON A HIGHWAY.

DISCLAIMER

THIS IS A HIGH PERFORMANCE PRODUCT. USE AT YOUR OWN RISK

Do not use this product until you have carefully read the following agreement.

This sets forth the terms and conditions for the use of this product. The installation of this product indicates that the BUYER has read and understands this agreement and accepts the terms and conditions.

DISCLAIMER OF LIABILITY

Quadzilla Performance Technologies, Inc. and its distributors, jobbers and dealers (hereafter SELLER) shall in no way be responsible for the product's proper use and service. THE BUYER HEREBY WAIVES ALL LIABILITY CLAIMS.

The BUYER acknowledges that he/she is not relying on the SELLER's skill or judgment to select or furnish goods suitable for any particular purpose and that there are no liabilities which extend beyond the description on the face hereof and the BUYER hereby waives all remedies or liabilities, expressed or implied arising by law or otherwise, (including without any obligations of the SELLER with respect to fitness, merchantability and consequential damages) or whether or not occasioned by the SELLER's negligence.

The SELLER disclaims any warranty and expressly disclaims any liability for personal injury or damages. The BUYER acknowledges and agrees that the disclaimer of any liability for personal injury is a material term for this agreement and the BUYER agrees to indemnify the SELLER and to hold the SELLER harmless from any claim related to the item of the equipment purchased. Under no circumstances will the SELLER be liable for any damages or expenses by reason of use or sales of such equipment.

The SELLER assumes no liability regarding the improper installation or misapplication of its products. It is the installer's responsibility to check for proper installation and if in doubt, contact the manufacturer.

LIMITATION OF WARRANTY

Quadzilla Performance Technologies, Inc. (hereafter "SELLER") gives limited warranty as to description, quality, merchantability, fitness for any product's purpose, productiveness, or any other matter of SELLER's product herewith. The SELLER shall be in no way responsible for the product's open use and service and the BUYER hereby waives all rights other than those expressly written herein. This warranty shall not be extended or varied in, except by a written instrument signed by SELLER and BUYER.

The warranty is limited to one (1) year from the date of sale and limited solely to the parts contained within the product's kit. All products that are in question of Warranty must be returned shipping prepaid to the SELLER and must be accompanied by a dated proof of purchase receipt. All warranty claims are subject to approval by Quadzilla Performance Technologies, Inc.

Under no circumstances shall the SELLER be liable for any labor charged or travel time incurred in diagnosis for defects, removal, or reinstallation of this product, or any other contingent expenses.

Under no circumstances shall the SELLER be liable for any damages or expenses incurred by reason of the use of sale of any such equipment.

IN THE EVENT THAT THE BUYER DOES NOT AGREE WITH THIS AGREEMENT: THE BUYER MAY PROMPTLY RETURN THIS PRODUCT, IN A NEW AND UNUSED CONDITION WITH A DATED PROOF OF PURCHASE TO THE PLACE OF PURCHASE WITHIN THIRTY (30) DAYS FROM THE DATE OF PURCHASE FOR A FULL REFUND.

THE INSTALLATION OF THIS PRODUCT INDICATES THAT THE BUYER HAS READ AND UNDERSTANDS THIS AGREEMENT AND ACCEPTS ITS TERMS AND CONDITIONS.



6032 JACKSBORO HWY, STE 100
FORT WORTH, TX 76135
TOLL FREE 1-888-842-6572

WWW.QUADZILLAPOWER.COM